

Preface

Thank you for purchasing HYT TC-320 Business Radio. TC-320 is unique for its compact and delicate body. It is ergonomically designed to give you exceptional experience of portability.

This easy-to-use radio will deliver you secure, instant and reliable communications at peak efficiency. Please read this manual carefully before use. The information presented herein will help you to derive maximum performance from your radio.

MODELS COVERED IN THIS MANUAL

TC-320 UHF Two-way Radio

Contents

Safety Information	2
Product Inspection	3
Radio Overview	4
Battery Information.....	6
Antenna Information	9
Assembly and Disassembly	10
Attaching/Removing the Battery.....	10
Attaching/Removing the Antenna.....	11
Attaching/Removing the Belt Clip.....	12
Attaching/Removing the Battery When the Belt Clip is Attached	13
Attaching/Removing the Earpiece/Mini USB.....	13
Basic Operations	14
Turning the Radio On/Off	14
Adjusting the Volume.....	14
Selecting a Channel.....	14
Transmitting	14
Receiving	14
Programmable Auxiliary Functions	14
Advanced Operations.....	15
CTCSS/CDCSS.....	15
Battery Save	15
Power Adjust.....	16
Time-out Timer (TOT)	16
Battery Strength Indicator	16
Monitor	17
Scan.....	17
Busy Channel Lockout (BCL)	19
Low Battery Alert.....	19
VOX (Voice-Operated Transmit)	19
Troubleshooting	21
Care and Cleaning.....	22
Optional Accessories.....	22

Safety Information

The following safety precautions shall always be observed during operation, service and repair of this equipment.

- ◇ This equipment shall be serviced by qualified technicians only.
- ◇ Do not modify the radio for any reason.
- ◇ Use only HYT supplied or approved batteries and chargers.
- ◇ To avoid electromagnetic interference and/or compatibility conflicts, turn off your radio in any area where posted notices instruct you to do so. Turn off your radio before boarding an aircraft. Any use of a radio must be in accordance with airline regulations or crew instructions.
- ◇ For vehicles with an air bag, do not place a radio in the area over an air bag or in the air bag deployment area.
- ◇ Turn off your radio prior to entering any area with explosive and flammable materials.
- ◇ Do not charge your battery in a location with explosive and flammable materials.
- ◇ Turn off your radio before entering a blasting area.
- ◇ Do not use any portable radio that has a damaged antenna. If a damaged antenna comes into contact with your skin, a minor burn can result.
- ◇ Do not expose the radio to direct sunlight over a long time, nor place it close to heating source.
- ◇ When transmitting with a portable radio, hold the radio in a vertical position with the microphone 3 to 4 centimeters away from your lips. Keep antenna at least 2.5 centimeters away from your body when transmitting.








WARNING: If you wear a radio on your body, ensure the radio and its antenna are at least 2.5 centimeters away from your body when transmitting.

Product Inspection

Please unpack the package box carefully and check that all items shipped are received; report any missing or damaged items to your dealer.


Accessories

Item	Qty. (PCS)
Antenna	1
Nylon Strap	1
Belt Clip	1
Screw (Belt Clip)	2
Li-Ion Battery	1
Switching Power	1
Owner's Manual	1

			
Antenna	Li-Ion Battery	Switching Power (varying in different countries and regions)	Nylon Strap
			
Belt Clip			

Note: Frequency band is marked on the label of antenna, if not, please refer to the label on the radio unit for detailed frequency band information.

Radio Overview



(1) PTT (Push-to-Talk) Key	(2) SK (Side Key)	(3) Speaker	(4) Volume Adjust Keys [+] / [-]
(5) Microphone	(6) Nameplate	(7) Charging Terminal	(8) Antenna
(9) Power Switch	(10) Channel/Status Indicator	(11) Channel Selector Knob	(12) Charge Indicator
(13) Accessory Jack Cover	(14) Audio Accessory Jack	(15) Mini USB Jack	(16) Strap Hole
(17) Screw (Belt Clip)	(18) Belt Clip	(19) Rear Cover	(20) Battery Latch

* PTT (Push-to-Talk) Key

Press and hold down the **PTT** key to transmit, and release it to receive.

* SK (Side Key)

Side Key is a programmable key that can be assigned with long/short press functions by your dealer.

Note:

Short Press: Key press shorter than 1 second.

Long Press: Key press longer than 1 second.

*** Status Indicator**

Status indications and alert tones are shown in the table below:

Power on (to enter user mode)	When the radio is turned on, the power on alert tone sounds and Status Indicator flashes orange once. When the current channel is a blank channel, the radio sounds beep tone continuously.
Power off	When the radio is turned off, the power off alert is heard.
Low battery alert	Status Indicator flashes red, and a low-pitched tone sounds at intervals of 10 seconds.
Transmitting	Status Indicator glows red when transmitting. When TOT timer expires, the radio sounds beep tone continuously. TOT pre-alert: A beep is heard.
Receiving	Status Indicator glows green when carrier is present.
Scanning	Status Indicator flashes green once every 1 second, while scanning is in process. Scan Start Alert Tone (programmable by your dealer): A beep is heard. When signal is received on a certain channel, Status Indicator solidly glows green. Scan Exit Alert Tone (programmable by your dealer): A beep is heard.
Power adjust	A low-pitched tone is heard when transmit power is switched from high power to low power.

	A high-pitched tone is heard when transmit power is switched from low power to high power.
VOX	One beep sounds when the VOX feature is activated. Two beeps sound when the VOX feature is disabled.

*** Battery Latch**

Used to secure or remove the battery.

*** Audio Accessory Jack**

Used to connect audio accessories such as earpieces.

*** Mini USB Jack**

Used to connect accessories such as programming cable, cloning cable and power cord.

Battery Information

Initial Use

New batteries are shipped not fully charged from the factory. Charge a new battery for 5 hours before initial use. The maximum battery capacity and performance is achieved after three full charge/discharge cycles. If you notice the battery power runs low, please recharge the battery.

Applicable Battery Packs

To reduce the risk of injury, charge only the battery specified by the manufacturer. Other batteries may burst, causing bodily injury and damage.

Caution:

1. To avoid risk of personal injury, do not dispose of batteries in a fire!
2. Dispose of batteries according to local regulations (e.g. recycling). Do not dispose as household waste.
3. Never attempt to disassemble the battery.

Battery Tips

1. When charging your battery, keep it at a temperature among 5°C - 40°C. Temperature

out of the limit may cause battery leakage or damage.

2. When charging a battery attached to a radio, turn the radio off to ensure a full charge.
3. Do not cut off the power supply or remove the battery when charging a battery.
4. Never charge a battery that is wet. Please dry it with soft cloth prior to charge.
5. The battery will eventually wear out. When the operating time (talk-time and standby time) is noticeably shorter than normal performance, it is time to buy a new battery.
6. In case the radio shuts off automatically at low battery power, recharge the battery promptly, or the battery could suffer damage.
7. Remove the battery before you store the radio for a long time, or the battery could suffer damage.

To Prolong Battery Life

1. Battery performance will be greatly decreased at a temperature below 0°C. A spare battery is necessary in cold weather. The cold battery unable to work in this situation may work under room temperature, so keep it for later use.
2. The dust on the battery contact may cause the battery cannot work or charge. Please use clean dry cloth to wipe it before attaching the battery to the radio.


Battery Storage

1. Fully charge a battery before you store it for a long time, to avoid battery damage due to over-discharge.
2. Recharge a battery after several months' storage (Li-Ion & Li-polymer batteries: 6 months), to avoid battery capacity reduction due to over-discharge.
3. Store your battery in a cool, dry place under room temperature, to reduce self-discharge.

Charging the Battery

When the Status Indicator flashes red and an alert tone sounds at intervals of ten seconds indicating the battery power runs low, please recharge the battery. Use only the charger specified by the manufacturer. The Charge Indicator indicates the charging progress.

Please follow these steps to charge your radio using the switching power or charger:




1. Plug the AC connector of the switching power into the AC outlet socket.
2. Plug the Mini USB connector of the switching power into the Mini USB jack of the radio or charger.
3. Place the radio with the battery attached in the charger when the charger indicator glows green to indicate the power supplies normally. (Please skip this step if you don't use a charger)
4. Make sure the radio is connected to the switching power or the charger. The charging process initiates when the Charge Indicator of the radio glows red.
5. The Charge Indicator glows green when the battery is fully charged. Please remove the radio then.

Status	Charge Indicator of the Radio
Battery is charging.	Charge Indicator solidly glows red.
Battery is fully charged.	Charge Indicator solidly glows green.

Note: Make sure the radio is attached with a battery before charging, and is powered off during charging.

Please follow these steps to charge a battery using the desktop charger:



1. Plug the AC connector of the switching power into the AC outlet socket.
2. Plug the Mini USB connector of the switching power into the Mini USB jack of the charger. Indicator of the charger glows green.
3. Place the battery in the charger.
4. Make sure the battery is connected to the charger. The charging process initiates when the charger indicator glows orange.
5. The charger indicator glows green when the battery is fully charged. Please remove the battery then.

Status	Charger Indicator
Battery is charging.	Charger Indicator solidly glows orange.
Battery is fully charged.	Charger Indicator solidly glows green.

Antenna Information

- Stubby antenna is durable, and is ideal for communication at low transmit power.
- Communication range may vary with terrain and your operating conditions. Rainy days or forest locations may narrow your communication range, please make preparation in advance to avoid potential inconvenience.

Assembly and Disassembly

Attaching/Removing the Battery

Attaching the Battery

1. Hold the top part of the radio's body, and slide the battery latch in the direction of arrow ①. Then lift the rear cover and remove it from the radio's body, as shown in Figure 1.




Figure 1

2. Align the discharging terminal of the battery with the radio's charging piece, and insert the tab at the top of the battery into the slot at the top of the radio's body. Then press the bottom of the battery towards the radio, until the battery is securely inserted into the battery slot, as shown in Figure 2. Note: If the battery is not well locked, please remove the battery and attach it again.




Figure 2

3. Fit the two extensions at the top of the rear cover into the slots at the top of the radio's body, slightly press the bottom of the rear cover towards the radio until a click is heard, and then the rear cover is securely attached to the radio, as shown in Figure 3.

Note: If the rear cover is not well locked, please remove the rear cover and attach it again.




Figure 3

Removing the Battery

1. Turn off the radio, if it is turned on. Then follow step 1 in the section “Attaching the Battery” to remove the rear cover.
2. Hold the top part of the radio's body, and lift the battery in the direction of arrow ① by the notch at its bottom, and then remove the battery from the radio's body in the direction of arrow ②, as shown in Figure 4.




Figure 4

Attaching/Removing the Antenna

Attaching the Antenna

1. Align the threaded end of the antenna with the radio's antenna connector.
2. Turn the antenna clockwise to fasten it, as shown in Figure 5.




Figure 5

Removing the Antenna

Turn the antenna counter-clockwise until you can remove it.

Attaching/Removing the Belt Clip

Attaching the Belt Clip

Align the two screw holes on the metal bracket of the belt clip with holes on the elliptical protrusion on the back side of the radio. Then secure the belt clip on the back side of the radio, as shown in Figure 6. Align the belt clip screws with screw holes on the metal bracket of the belt clip, and then secure the screws.




Figure 6

Removing the Belt Clip

Loosen the screw to remove the belt clip. Please refer to the operations for attaching the belt clip.

Attaching/Removing the Battery When the Belt Clip is Attached

When the belt clip is attached to the radio, please first press the belt clip to make its bottom up, and then attach/remove the rear cover and battery by the steps mentioned above, as shown in Figure 7.




Figure 7

Attaching/Removing the Earpiece/Mini USB

Attaching the Earpiece/Mini USB

1. Open (not remove) the accessory cover, plug the audio accessory firmly into the accessory jack, and the Mini USB into the USB jack, as shown in Figure 8.




Figure 8

Removing the Earpiece/Mini USB

Open the accessory cover, and then remove the earpiece or Mini USB.

Note: Use of audio accessory may affect the waterproof performance of the radio.

Basic Operations

Turning the Radio On/Off

Long press the **Power Switch** until an alert tone is heard to turn the radio on.

To turn the radio off, do the same as you turn it on.

Adjusting the Volume

You may adjust the volume level through **Volume Adjust Keys** **[+]/[-]**. Press the **[+]** key to increase the volume, or press the **[-]** key to decrease the volume.

Selecting a Channel

Turn the **Channel Selector** knob to select a channel. Make sure the desired channel number points at the Channel Indicator.

Transmitting

To transmit, press and hold down the **PTT** key, and then speak into the microphone at normal voice level. Hold the radio about 2.5 to 5 centimeters away from your mouth.

Receiving

Release the **PTT** key to receive.

Programmable Auxiliary Functions

The **SK** key is a programmable function button. Your dealer may assign any of the following auxiliary functions to a short or long programmable key-press.

- None
- Power Adjust
- Monitor
- Monitor Momentary

- Scan
- Scrambler
- VOX (Voice-Operated Transmit)
- Compandor
- Squelch Off
- Squelch Off Momentary
- Battery Strength Indicator
- Channel Lock (If you rotate the **Channel Selector** knob with Channel Lock function enabled, the current channel number will remain unchanged. This function will not be disabled after programming.)

Advanced Operations

The following functions are programmable by your dealer.

CTCSS/CDCSS

Set up talkgroups with unique CDCSS/CTCSS to prevent unwanted conversations on the same frequency. If CTCSS/CDCSS has been set on the current channel, CTCSS/CDCSS match is required for the radio to unmute to an incoming signal. If CTCSS/CDCSS is not set, the radio can receive calls from all users operating on the same frequency. Your dealer may set CTCSS/CDCSS for some channels.

This feature does not mean that your conversation will not be heard by others. Radios with the same CTCSS/CDCSS or with no CTCSS/CDCSS, can receive calls from you.

Battery Save

The Battery Save feature will be automatically activated once no activity is present on the channel and no operation is performed (no key press and no knob selection), for extended operation time.

Once the radio detects no activity on the channel and no operation performed (no key press and no knob selection) during radio standby time, it will automatically enter sleep

mode ten seconds later. Pressing any key or receiving a signal will cause the radio to exit from Battery Save and restore it to normal operation.

Power Adjust

Users can switch the Tx power level between high and low power by pressing the programmed **Power Adjust** key.

Time-out Timer (TOT)

The TOT timer limits the amount of time the radio can continuously transmit on a channel. This can also protect your radio from damage due to excessive transmission. If the user holds down the **PTT** key longer than the preprogrammed time period, the radio will automatically stop transmitting and generate a warning tone. To stop the warning tone, release the **PTT** key.

Your dealer may program the alert tone that sounds before the TOT timer nearly expires.

Battery Strength Indicator

TC-320 allows you to simply press the programmed **Battery Strength Indicator** key to illuminate the Status Indicator, which gives different indications representing battery strength levels. To exit the indications, release the key.

The Status Indicator gives the following indications to represent corresponding battery strength levels:

Battery Strength	Status Indication
70%-100%	Status Indicator solidly glows green.
50%-70%	Status Indicator solidly glows orange.
30%-50%	Status Indicator solidly glows red.
10%-30%	No indication is given when the programmed key is pressed; Status Indicator flashes red while the radio is operating.
Less than 10%	No indication is given when the programmed key is pressed. While the radio is in standby mode, Status Indicator flashes red and a low-pitched tone sounds at intervals of ten seconds. If PTT key is

	pressed at the moment, the radio will give an alert indicating that transmission is prohibited.
--	---

Monitor

- **Squelch Off**

Purpose: In this mode, the speaker is unmuted in any condition so as to receive any sound on the current channel. When audio signal is received on the channel, audio will be heard. Otherwise, background noise will be heard.

Operation: Press the **Monitor** key to enter this mode, and press it again to exit.

- **Squelch Off Momentary**

Purpose: Refer to **Squelch Off**.

When audio signal is received on the channel, audio will be heard. Otherwise, background noise will be heard.

Operation: Hold down the programmed key continuously to enter this mode, and release the key to exit.

- **Monitor**

Purpose: In this mode, the receiving party can receive incoming calls from the transmitting party regardless of CTCSS/CDCSS condition. If the carrier condition is not satisfied, the receiving party will fail to receive any incoming calls.

Operation: Press the **Monitor** key to enter this mode, and press it again to exit.

- **Monitor Momentary**

Purpose: Refer to **Monitor**.

Operation: Hold down the programmed key continuously to enter this mode, and release the key to exit.

Scan

The Scan feature enables a two-way radio to continuously scan each channel for activity. Press the programmed **Scan** key to initiate scanning channels in the order as they appear in scan list. Status Indicator flashes green during the scan process, and solidly glows

when activity is detected and signaling condition is satisfied on a channel. Press the key again to exit scanning.

When scanning is active, the radio will continuously scan for activity on scan list members. Once activity is detected on a channel, scanning will pause on the active channel for you to receive activity. The channels available for scanning are programmed by your dealer.

No Priority Channel

Providing that there is a scan list with 6 channels and all channels are non-prioritized, the normal scan operation would proceed in the following sequence, as shown in Figure 1.




Figure 1 Normal Scan Sequence

Priority Channel Scan

If you prioritize Channel 2 as Priority 1, the scan operation would proceed in the following sequence, as shown in Figure 2.




Figure 2 Priority Scan Sequence

● Scan On/Off

You can enter scan mode through any of the following two methods:

(1) Key Operation

Press the programmed **Scan** key to enter scan mode, provided that there're no less than 2 members in the scan list. Press the **Scan** key again or power off to exit.

(2) Auto

If Auto Scan is enabled for a channel, the radio will automatically enter scan mode when it is switched to this channel. When it is switched to other channels or powers off, the radio will exit from scan mode.

● **Talk Back**

This option defines whether users can talk back on the channel where scanning pauses. When the option is checked, users can do so.

If the scanning does not pause on any channel, users may talk back on the predefined channel.

● **Priority Channel Scan**

This function enables users to scan the most frequently used channel so that messages will not be missed. The priority channel is programmed by the dealer via programming software. Contact your dealer for details.

Note: Even though the radio remains on a non-priority channel, activities on the priority channel are still under monitoring. The radio will switch to the priority channel once any activity is detected.

● **Available Keys in Scan Mode**

PTT key, Volume Adjust keys **[+]** / **[-]**, and 4 programmable keys of Squelch Off, Squelch Off Momentary, Monitor and Monitor Momentary.

Busy Channel Lockout (BCL)

This function can help avoid interference between radios operating on the same channel. When the channel is already in use, the radio will sound a continuous warning tone and return to Receive mode upon **PTT** press. To cancel the tone, release the **PTT** key.

Low Battery Alert

When battery power runs low, Status Indicator will flash red and a low-pitched tone will sound every ten seconds to remind users to replace the battery.

VOX (Voice-Operated Transmit)

With the dedicated VOX earpiece, you can enjoy hands-free communication. After this

function is enabled, the radio will automatically begin transmitting when you speak, and terminate transmitting when you stop talking, with no need of **PTT** press.

Operation Steps:

1. Push the PTT/VOX switch on the earpiece to VOX.
2. Plug the earpiece into the accessory jack of the radio.
3. Press the programmed **VOX** key to activate the VOX feature.
4. When no signal is received, speak through the microphone of the earpiece and your voice will be transmitted.

Operation Instructions:

1. Press the **PTT** key on you radio to disable the VOX during its operation, and release **PTT** key to reactivate this function.
2. Press the programmed **VOX** key to enable/disable the VOX feature, with corresponding alert tone. When it is enabled, the alert tone sounds once; when it is disabled, the alert tone sounds twice.
3. The VOX feature will be disabled automatically after the radio is turned off or programmed.
4. The VOX function will work with a dedicated earpiece.
5. Your dealer may set VOX sensitivity or disable the VOX feature through the programming software. The **VOX** key will be null when the VOX feature is disabled.

Note:

1. VOX / PTT function switch can be realized in this way: unplug the earpiece → switch between VOX and PTT → plug the earpiece.
2. After the above operations are completed, it takes approximately 2-3 seconds for the radio to perform auto-detection until it operates normally. To avoid breakdown caused by expected detection error, do not use the earpiece during auto-detection process.
3. If the earpiece operates abnormally, please pull and plug it again as instructed above.
4. You may select VOX levels according to the operating environment. Too much noise and high VOX level may cause the radio to transmit continuously.
5. Use only the VOX earpieces specified by HYT. Please plug a VOX earpiece into the radio's jack properly, or the VOX function may not work.

Note: To purchase accessories, please contact your local dealer.

Troubleshooting


Symptom	Solution
Cannot power on the radio.	<ul style="list-style-type: none">● The battery has run out. Please recharge the battery or replace it with a new one.● The battery is not properly installed. Please remove the battery and attach it again.
The operating time is noticeably shorter than normal performance, even though the battery is properly charged.	<ul style="list-style-type: none">● The battery has worn out, and it is time to buy a new battery.● The battery is not fully charged. Make sure the charge indicators glow green.
Cannot talk to or hear group members.	<ul style="list-style-type: none">● Make sure you are on the same channel - check whether the Channel Lock function is enabled or other channels are locked by error. If you rotate the Channel Selector knob with Channel Lock function enabled, the current channel number will remain unchanged.● Make sure radios have the same channel and the same CTCSS/CDCSS settings.● Make sure you are within their communication range.
Hear non-group members	<ul style="list-style-type: none">● Send the radio to your dealer to change your CTCSS/CDCSS settings, and so as your group members.
No voice or low voice while transmitting	<ul style="list-style-type: none">● Make sure the volume is turned up to its maximum value.● Send the radio to your dealer for microphone examination.
Noise always on	<ul style="list-style-type: none">● Group members are too far away to receive their call. Please go within the communication range and re-power on the radio to try.

Care and Cleaning

- Do not hold the radio by its antenna or external earpiece directly.
- Do not place the radio in a dusty or dirty environment.
- Clean the radio with a lint-free cloth to remove dirt or grease, to avoid poor contact due to excessive dust.
- Clean the radio using a lint-free cloth moistened with clean water and a mild dishwashing liquid.
- Avoid subjecting the radio to corrosives, solvents or spirits.

Optional Accessories

			
Earbud with In-Line PTT ESS09	Earset with In-Line MIC & PTT & VOX EHS09	Remote Ring PTT Switch (Mini USB port) POA18	Six-Unit Switching Power PS4001 (For use with different power cords in different countries and areas)
			
Rapid-Rate Charger (For Li-Ion Battery) CH05L01	Vehicle Power Adapter PV1001	Wrist Strip (Nylon) NCN004	PU Carrying Case (Non-swivel) (Blue) PCN002

			
Waterproof Bag LCYY02 (Yellow)			

Note: Pictures are for reference only and may vary from actual product. Product function shall remain the same.

The above listed items are the common optional accessories for your radio. To order other accessories, please contact your local dealer.

HYT endeavors to achieve the accuracy and completeness of this manual, but no warranty of accuracy or reliability is given. All the above specifications and design are subject to change without notice due to continuous development.

No part of this manual may be copied, reproduced, translated, stored in a retrievable system, distributed, or transmitted in any form or by any means, electronic or mechanical, for any purpose without the express written permission of HYT.